Colomer & Sons
SPAIN

USER INSTRUCTIONS



1.Start:
Being an automatic watch we suggest you wind it up completely the first time you use it (Position 1) Unscrew the crown and in this position rotate. The crown will need to be wound manually 15 – 20 times to develop a sufficient power reserve to ensure the accuracy of the timepiece. You do not have to repete this action every day while the watch is in use, the watch will charge itself automatically.
2. Setting of the time:
Pull out the crown (Position 2) and move the hands to the desire time.
3. Adjusting the date:
There are 2 ways of doing this: By pressing the pusher (A) situated on the superior external left side of the watch, or when adjusting the time every 24 hours by moving the hands (Position 2). If the month has fewer days, it must be adjusted manually.
4. Adjusting the day:
There are 2 ways of doing this: By pressing the pusher (B) situated on the inferior external left side of the watch, or when adjusting the time every 24 hours by moving the hands (Position 2).
Note:
* The date and day changes somewhere between 0:00 am and 5:30 a.m. hours or a little later.
5. Adjusting the month:
By pressing the pusher (C) situated on the inferior external right side of the watch