

## VISUALIZACIÓN DEL RELOJ WATCH DISPLAY



## INSTRUCCIONES DE USO

### AJUSTE DE LA HORA:

Tire de la corona hasta la posición 2. Gire la corona para ajustar las manecillas de horas y minutos. Vuelva a poner la corona en la posición 0.

### USO DEL CRONÓGRAFO:

1. Pulse el botón A para poner en marcha el cronógrafo. La manecilla que cuenta los segundos empezará a moverse.
2. Presione el botón A de nuevo si quiere detener el cronógrafo. La manecilla que cuenta los segundos se parará, indicando el tiempo transcurrido.
3. Presione el botón B para reiniciar el cronógrafo. Todas las manecillas del cronógrafo se pondrán en la posición "0".

### SOBRE EL CRONÓGRAFO:

El cronógrafo puede cronometrar hasta un total de 60 minutos.  
El cronógrafo se detendrá una vez alcanzados los 60 minutos de medición.

## USER MANUAL

### SETTING THE TIME:

*Pull out the crown to the position 2. Turn the crown to adjust the hour and minute hands. Return the crown back to position 0.*

### HOW TO USE THE CHRONOGRAPH:

1. Press button A to start the chronograph. The chronograph second hand will start moving.
2. Press button A another time to stop the chronograph. The chronograph hands stop to indicate the elapsed time.
3. Press button B to reset the chronograph. All the chronograph hands will be reset to "0" position.

### ABOUT THIS CHRONOGRAPH:

*The chronograph can measure up to 60 minutes.  
The chronograph stops after a measuring 60 minutes.*

