Colomer & Sons
SPAIN

USER INSTRUCTIONS



1.Start:
Being a hand winding watch you should wind it up completely the every time you use it (Position 1) Unscrew the crown and in this position rotate. The crown will need to be wound manually 15 – 20 times to develop a sufficient power reserve to ensure the accuracy of the timepiece. take care not to over do it. As you wind it you will notice that the rotor becomes charged, stop when it becomes harder. Fully charged, the power reserve lasts approximately 42 hours. You will have to wind the watch every 40 hours, to preserve the watch working well.
2. Setting of the time:
Pull out the crown (Position 2) and move the hands to the desire time.
3. Using the chronograph:
To measure any kind of phenomenon, simply press the top right button (A) for the chronograph to start working, to stop it press the same button (A) once again.
To return the chrono hand to zero, press the bottom button (B). If you measure more than a minute, you will see that the dragging counter minute at 3 o'clock will start to count them, going up to 30 minutes.