Colomer & Sons
SPAIN

# USER INSTRUCTIONS




A) SETTING THE TIME

1. Pull out the crown (Position 3) and move the hands to the desire time.

3. When the crown is pushed back to (Position 1), small second hand begins to run.

B) SETTING AND READING THE AGE OF THE MOON

* The moon phase represents the age of the moon, the actual shape of the moon during each phase is not represented.

* Use the moon phase only as a guide to the age and phase of the moon when reading and setting watch.

1. SETTING THE AGE OF THE MOON

Pull the crown out to the "Position 2".

Turn the crown clockwise to advance the moon phase.

2. SETTING THE AGE OF THE MOON WITH AGE SCALE

* Check on the age of the moon for the day. Check the newspaper or other source for the age or phase of the moon for today or tomorrow. Subtract one day before a setting is made if the listings for tomorrow are used.

* Setting procedure (Example: age of the moon: 4.4

Pull the crown out to the "Position 2".

Turn the moon disc clockwise until the center of the moon is in line with 4.4 on the scale.

3. SETTING THE AGE OF THE MOON WITHOUT THE AGE SCALE

* Check the newspaper or other source that lists current age or phase of the moon.

More accurate setting can be made at the same time of the new moon (0) or full moon(15).

THE AGE OF THE MOON

The age of the moon is indicated in units of days. The average period from a new moon to the next new moon is equivalent to about 29.5 days.