


USER MANUAL



QUICK ROLLER ALIGNMENT CHECK

Press button D three times in succession. The rollers should stop aligned at the 12:00 position. If the roller alignment is correct, press any button to exit quick check mode and proceed to set the time. If not, you will need to follow the instructions and reposition the rollers to align them before making the time adjustment.

SETTING THE CURRENT TIME

1. Press button B for 2 seconds. The hour roller will move indicating that it receives the signal to change the time.
2. Press button B as many times as necessary to advance the hour roller until it is set to the current time.
3. Press button C for 2 seconds to advance the first minute roller. Press and hold if you want it to move faster.
4. Press button D for 2 seconds to advance the second minute roller. Press and hold if you want it to move faster.
5. After setting the time, press button A or wait 15 seconds for the rollers to be fixed in the correct position again.

REPOSITIONING THE ROLLERS TO ALIGN THEM

1. Press button A for 2 seconds to enter setup mode. The rollers will begin to spin until they stop.
2. Next use buttons B, C and D to put the rollers aligned at the 12:00 position. Short press to advance little by little or long press to speed up the operation.
3. After aligning the numbers at the 12:00 position, press button A or wait 15 seconds for the rollers to be fixed in the correct position again.

ANIMATED DEMONSTRATION MODE

Press button C once. The spin wheel will rotate twice to demonstrate the movement of the rollers. It will return to normal time once the demo has